

MOUNTING LOCATION:

Multi-Locations

TOOLS REQUIRED:

T-25 Torx Driver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT**INSTALLATION INSTRUCTIONS**

PART#: 75141-508

MFG: FREIGHTLINER

MODELS & YEARS:

Cascadia 125 Evolution 2013-2018

Cascadia 126 2008-2017

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With the T-25 Torx driver, remove ant screws that hold the dash plates in place. You may need to remove more than (1) screw to get the mount in place.

STEP #2: Lift up on the dash bezel and place the InDash by PanaVise over the screw hole, and Reinstall the screws.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Prototype installed showing (3) of Many locations



02-06-18